

Instruktioner














H05RN-F/3G1.0  
H07RN-F/3G1.5








[www.harald-nyborg.dk](http://www.harald-nyborg.dk)



<p>A1</p>  <p>3 stk</p>	<p>A2</p>  <p>3 stk</p>	<p>A3</p>  <p>3 stk (kun til IP44)</p>	<p>A4</p>  <p>3 stk (kun til IP44)</p>
--	--	---	---



**Forsigtig – Risiko for elektrisk stød!**

Lyskilden i dette armatur må kun erstattes af fabrikanten eller en tilsvarende kvalificeret person.

	<b>P</b>	<b>I</b>	<b>λ</b>		<b>IP</b>
F50500SM	10.5W	91mA	>0.5	Ø280 x H100	IP20
F50700SM	18.5W	161mA	>0.5	Ø390 x H110	IP20

220-240V~    50/60 Hz    Ta -30°C ~ +40°C   
 



